

Piece #1

Pieces 2 and 3



Unassembled octagon kit of 3 pieces.

From left to right. Pieces are numbered 1 2 and 3.



Set interlocking pieces 2 and 3 together at a 90 degree angle



Finish the assembly by putting tabletop (piece #1) on top of of pieces 2 and 3.

Note: tabletop is slotted on the bottom to keep it securely in place, no need for any fasteners.