


Assembly Directions for Glider Chair and Base



STEP #1 -

First slide the Glider Base underneath the Glider Chair, ensuring the correct end of the base is pointed forward (*see photo*). Then lift the Glider Brackets onto the $\frac{5}{16}$ " x $2\frac{1}{2}$ " Carriage Bolts of the Glider Base. Using 4- $\frac{5}{16}$ " Lock Nuts, secure Glider Bracket onto the Bolt. Last, using 4- $\frac{5}{16}$ " Acorn Nuts, hand tighten on the bolt.



STEP #2 -

Repeat Step #1 on the other side of your Glider. Your Glider is now complete!

Assembly Directions for Double Gliders

#PCTG2400, #PZTG2400



Double Cozi-Back Glider



Double Comfo-Back Glider

PACKAGE CONTENTS



- 2 Bases
- 1 Back
- 1 Seat
- 1 Hardware Package
- 2 Arms with Legs
- 2 Cross Supports
- 4 Stops
- 1 Glider Bracket Package

HARDWARE PACKAGE


- 2 $\frac{1}{4}$ " x $4\frac{1}{2}$ " Carriage Bolts
- 2 $\frac{1}{4}$ " x $3\frac{1}{2}$ " Carriage Bolts
- 7 $\frac{1}{4}$ " x 3" Carriage Bolts
- 8 $\frac{5}{16}$ " x $2\frac{1}{2}$ " Carriage Bolts
- 8 $\frac{5}{16}$ " Lock Nuts
- 8 $\frac{5}{16}$ " Flange Nuts
- 18 $\frac{1}{4}$ " Flange Nuts
- 4 $\frac{5}{16}$ " Acorn Nuts
- 4 Glider Brackets

TOOLS NEEDED:

- Hammer
- $\frac{7}{16}$ " Wrench
- $\frac{1}{2}$ " Wrench




Use to measure bolts




Use to measure bolts




Assembly Directions for Glider Chair




STEP #1 - Fasten the Arm and Leg Assembly to the Seat and Back using 3- $\frac{1}{4}$ " Carriage Bolts. Using a hammer, firmly tap the Bolts until they are flush with the poly surface. Securely tighten using 3- $\frac{1}{4}$ " Flange Nuts.



STEP #2 - Turn the chair on the other side and repeat Step #1.




STEP #3 - Using 4- $\frac{5}{16}$ " x $2\frac{1}{2}$ " Carriage Bolts, place them into the pre-drilled holes and tighten using 4- $\frac{5}{16}$ " Flange Nuts. **(Ensure the Bolts are pointing inwards.)**




STEP #4 - Place the 4- Glider Brackets onto the Carriage Bolts and secure using 4- $\frac{5}{16}$ " Lock Nuts (*see inset*). Be careful not to cross thread the Lock Nuts.


Assembly Directions for Glider Base



STEP #1 - Fasten the two Cross Supports to the Base using 8- $\frac{1}{4}$ " x 2" Carriage Bolts and 8- $\frac{1}{4}$ " Flange Nuts.



STEP #2 - Attach the four Glider Stops to the Base using 4- $\frac{1}{4}$ " x 3" Carriage Bolts and 4- $\frac{1}{4}$ " Flange Nuts.



STEP #3 - Using 4- $\frac{5}{16}$ " x $2\frac{1}{2}$ " Carriage Bolts, place them into the pre-drilled holes and secure using 4- $\frac{5}{16}$ " Flange Nuts. **(Ensure the Bolts are pointing outward.)**